

Installation and operating instructions



# CALEC® energy master

## The benchmark for energy measurement technology

**Short version**

Firmware Version 1.00



VD 3-135 e, 07.2009

# 1 Contents

1	Contents	2	9	Operation	16
2	Information and references	3	9.1	PC-Software AMBUS Win II	16
2.1	Information	3	9.2	Display	16
2.2	Documents	3	9.2.1	Key functions	17
3	Safety notices	4	9.3	Right of access, security levels	17
3.1	Symbols used	4	10	Menu overview	18
3.2	Intended use	4	10.1	Main display and main menu	18
3.3	Inappropriate use	4	10.2	Submenus	19
3.4	Installation guidelines	5	11	Use under operating conditions	21
4	View of device with protective housing	6	11.1	The main display	21
5	View of device without protective housing (Mod)	7	11.2	The measured values submenu	22
6	Mounting the device with protective housing (Prot)	8	11.2.1	Measured values	22
6.1	Scope of supply, tools and mounting material (Prot)	8	11.2.2	Meter readings	22
6.2	Installation (Prot)	8	11.2.3	Current values	22
7	Mounting the device without protective housing (Mod)	12	11.2.4	Billing date values	22
7.1.1	Rail mounting	12	11.2.5	Logger values	22
7.1.2	Connecting to mains power supply 230 VAC	12	12	Dimensional drawings and technical specifications	23
7.1.3	Connecting to low voltage supply 24 VDC	13	12.1	Drawings of device with protective housing (Prot)	23
7.1.4	Connecting signal cables	13	12.2	Drawings of device without protective housing (Mod)	23
8	Electrical connections	14	12.3	Technical specifications	25
8.1	Connection instructions	14	13	EC declaration of conformity	28
8.2	Wiring diagram, module and signal numbers	14			
8.3	Numbering rules	15			

## 2 Information and references

### 2.1 Information

These installation and operating instructions describe the installation and commissioning of a standard device. The chapters describe the topics and tasks in the sequence in which they are needed during commissioning.

- Safety instructions
- Information about the device
- Installation
- Electrical connections
- Operation
- Fault clearance
- Technical data



**Always comply with the safety instructions.**

### 2.2 Documents

The installation and operating instructions VD 3-135 vary in scope, depending on the version and items covered by the delivery. The information required for ancillary modules and optional functions is described in additional document extracts (VD 3-136).

#### Parameterisation software AMBUS Win II

The parameterisation software AMBUS Win II is available for setting the parameters. It can be downloaded free of charge (see below).

#### Downloads

The current documents and AMBUS Win II are available as free downloads at [www.aquametro.com /downloads](http://www.aquametro.com/downloads).

## 3 Safety notices

### 3.1 Symbols used



#### Important information

Non-observance can lead to malfunction.



#### General warning

Non-observance can lead to damage or malfunction.



#### Warning of dangerous electric voltage

Non-observance can lead to physical injury!

### 3.2 Intended use

The device is used as an energy calculator for heating, cooling and air conditioning applications in district heating or cooling, in building management services and in industrial energy metering.

It is part of a combined heating/cooling or air conditioning meter, consisting of a calculator, a pair of temperature sensors and a flow meter, or as a transducer for a flow meter.

The environmental conditions described in the technical specifications, as well as the installation and operating instructions must be complied with.

### 3.3 Inappropriate use



#### The device must not be used:

- In explosion-risk zones (no ex-risk protection!)
- In a wet environment (condensing, splashing or dripping water)
- Outdoors, without suitable protection
- In environmental conditions (temperature, humidity, vibrations, electromagnetic interference etc.) that do not comply with the technical specifications
- In all other instances that do not conform to its intended use

The device can be dangerous if it is not used as intended, or not in accordance with the installation and operating instructions. In order to avoid this, it is essential that the safety instructions, operating conditions (see technical specifications) and the relevant chapters of these instructions are strictly adhered to.



**The manufacturer accepts no liability for damage arising from inappropriate use.**

### **3.4 Installation guidelines**



The installation should be performed by authorised, skilled personnel, in compliance with the regulations in force (EN1434 part 6 Regulations and recommendations for installation and operation) and the recommendations of the industry-specific associations (e.g. the AGFW series of leaflets on district heating supplies).




The skilled personnel must have read and understood these instructions. The requirements in the instructions and the applicable regulations on electrical installations must always be observed.




Work on electrical circuits with hazardous voltages (> 24 VAC or >42 VDC) may only be carried out by authorised, skilled people, in compliance with the locally applicable regulations!

## 4 View of device with protective housing



Device with closed protective housing


- 1 Housing cover
- 2 Operating keys
- 3 Dot-matrix LCD
- 4 Type plate with CE marking
- 5 IR interface on display module  
(EN13757-2 / -3 M-Bus)  
IrDA interface on CPU module
- 6 Housing screws, covered by security sealing caps



Device with opened protective housing

- 2 Operating keys
- 3 Display, LCD dot matrix
- 5 IR interface (EN13757-2 / -3 M-Bus)  
IrDA interface
- 7 Display module
- 8a Upper terminals, plug-in
- 8b Lower terminals, plug-in
- 9 Clip-on holder for modules
- 10 3 Fastening holes for wall mounting
- 11 Clip-on holder for rail mounting
- 12 Strain relief
- 13 Cover hinges

The wiring diagram is on the inside of the housing cover.




View of the protective housing from below


- 11 Clip for rail
- 14 Cable duct supply 14 mm
- 15 Cable ducts 10 mm
- 16 Cable ducts 14 mm

## 5 View of device without protective housing (Mod)

The following diagram shows the device without protective housing.



The Display can be installed at a remote location e.g. in a control panel by using the two Remote Display Adapters:





## 6 Mounting the device with protective housing (Prot)

### 6.1 Scope of supply, tools and mounting material (Prot)



**Warning!** Precision measuring devices! Protect against heat, humidity, dirt and vibration. Only unpack the device when ready to install. Non-observance can result in damage or malfunction.




1) Support rail optional

- One Installation and Operating Instructions manual

### 6.2 Installation (Prot)


#### Opening the housing



## Mounting on support rail (DIN-EN 50222)


Choose the location for installation

- which is protected against humidity, heat, direct sunlight and damage
- with easy access for reading, operation and installation
- with sufficient distance from sources of electromagnetic interference




1. Drill holes
2. Screw on support rail
3. Clip device onto support rail

## Wall mounting




Remove clip-on holder  
to get a stable support.



Only mount device on a  
flat surface!

## Wiring diagram




The wiring diagram is on the inside of the housing cover.

## Connecting to mains power supply 100 - 240 VAC


The mains supply must be connected via a two-pole separator and be adequately protected against unauthorised interruption.

	The mains supply 100 - 240 VAC may only be connected to the following terminals:	Terminals L, N (supply module) Terminals 110, 115 (relay module 2x240 VAC)
	<p>The device must be protected by a 10 AT external fuse. The device is fully isolated and requires no grounding connections. Connection to other terminals is extremely dangerous and can permanently damage the instrument!</p>	

## Connecting to low voltage supply 24 VDC




## Connecting signal cables



1. Pierce sealing membrane with enclosed awl
2. Insert cable
3. Attach cable to terminal screws according to wiring diagram on the inside cover
4. Affix strain relief clamp

## Closing housing



1. Insert the cover into the hinge from above and turn to close
2. Tighten the two fixing screws
3. Engage the **security sealing caps** with the smooth side on the outside.


Once the caps **③** have been fitted, any unauthorised opening of the device can be detected.

### Removing the caps:

Insert a pointed tool and lever out. The cap is damaged as a result and must be replaced.

## 7 Mounting the device without protective housing (Mod)

### 7.1.1 Rail mounting



1. Drill fastening holes
2. Screw on support rail
3. Clip modules onto support rail

### 7.1.2 Connecting to mains power supply 230 VAC




**Refer to the wiring diagram before starting wiring!**



The mains supply may only be connected to terminals L and N!


The device is fully isolated and requires no grounding connections.

All other terminals are only for low voltage (<50 V) and measuring signals. Connection to these terminals is extremely dangerous and can permanently damage the instrument!




1. Strip the power cable as shown in drawing.
2. Connect power cable to supply module (see enclosed wiring diagram)

### 7.1.3 Connecting to low voltage supply 24 VDC



1. Strip cable as shown in drawing
2. Attach cable to the connect module (see enclosed wiring diagram)

### 7.1.4 Connecting signal cables



1. Attach signal cables to terminal screws according to enclosed wiring diagram
2. The terminal blocks can be plugged in.

## 8 Electrical connections

### 8.1 Connection instructions



Devices with 100 - 240 VAC connections must have a safety fuse with a max. 10 AT, and must be capable of being made voltage-free by means of an isolating element!



The device must be connected to the same electric circuit and the same fusing, switching and isolating elements as the corresponding heating or cooling system.



If the device is additionally connected via fusing, switching and isolating elements, then these must be protected against unauthorised access (e.g. by security seals), so that the device cannot be put out of operation by unauthorised persons.

### 8.2 Wiring diagram, module and signal numbers

Below are two examples of wiring diagrams in which the module numbers and signal numbers or signal designations are shown:

Basic unit with 3 modules (right to left): M-101-Prot-AC[I]-CT	Fully assembled unit with 7 modules (right to left): EM-101-Prot-AC[MMOOI]-CT
<ul style="list-style-type: none"> <li>• CPU module 2 x Pt100</li> <li>• Input module for flow signal</li> <li>• Mains power supply (supply module)</li> </ul>	<ul style="list-style-type: none"> <li>• CPU module 2 x Pt100</li> <li>• Input module for flow signal</li> <li>• 2 output modules for 4 analogue output signals, e.g. for a building services management system</li> <li>• 2 M-Bus modules for data reading with 2 M-Bus master units</li> <li>• Mains power supply (supply module)</li> </ul>

- Designation:
- Module numbers
- Signal designation according to standard diagram of the application
- Designation:
- Signal numbers, without signal designation
- Signal designation according to the standard diagram of the application



**Note on input module:** Left-hand pair of terminals: Power via calculator  
 Right-hand pair of terminals: External supply

## 8.3 Numbering rules



**Basic rule:** The signals are numbered from right to left and from the top down.

This table shows the elements that have a number, and their maximum number.

Element	Display/number	Explanation
Module	Mod-No.1... 6 (Prot) * Mod-No.1...15 (Mod) *	Numbers according to assembly from right to left No. 1 is the CPU module The module for power supply has no number
Input	Input 1...8	Pulse, current or frequency signal
Pt100 input	Pt100 No.1...6	Pt100 inputs for temperature measurement
Output	Output 1...8 (Prot) * Output 1...12 (Mod)	Output 1 ...8, (short designation e.g. A1) Output 9 ...12 can be used virtually
Terminals	Trm.No. 82-10-11	See terminal marking
Tariff register	R1 ... R4	4 tariff registers per active calculator Display example: R 1 A2+ Tariff register 1 is active when output 2 is switched on.
Interfaces	Interface 1 ... 5	1Internal bus between the modules 2Optical M-Bus interface in the display module 3IrDA interface in the CPU module 4M-Bus module 1 5M-Bus module 2

\*: Prot: Device version with protective housing

Mod: Device version without protective housing

## 9 Operation

### 9.1 PC-Software AMBUS Win II


The parameters of the device can be set both via keys and display and via one of the data interfaces with the PC parameterising software AMBUS Win II.

With AMBUS Win II, the meter reading data can be saved, and parameter settings that have to be executed repeatedly can be stored as macros, which can then be reloaded and run. AMBUS Win II and the associated operating instructions can be downloaded free of charge at [www.aquametro.com](http://www.aquametro.com). The use of AMBUS Win II offers advantages if:

- large data records have to be read,
- several devices require identical or similar parameter settings,
- complex applications with inputs/outputs are to be parameterized.

AMBUS Win II and instructions are available as free downloads at [www.aquametro.com](http://www.aquametro.com).

### 9.2 Display



Symbols on the status bar	
	Currently available keys
*	A flow signal is being detected
EDIT	Edit mode active, input possible
	Protection level (see section 0) user, service, programming mode

### 9.2.1 Key functions

Keys	Function in display mode	Function in edit mode
	Move line/image up or down	Setting of figures and/or characters Selection from a preset list
	No function in the main menu Change channel / input / output Change billing date / logger period	Select setting position in the edit window Change list inside a double-list

Keys	Short (< 0.5 s)	Long (> 0.5 s)	Key operation
	Confirm	Activate/deactivate the 3 additional decimal points in the meter settings	Accept set value Accept selected value Finish edit mode
	Back to a previous level, abort process	Back to the standard display	Abort input / selection In double list: finish process

### 9.3 Right of access, security levels

The parameters for the device can be set entirely via the keys or via the interfaces. The security level (lock level) determines which parameters can be altered. At the time of delivery, the devices are in user mode.

Symbol	Security level	Settings	Code	At delivery
	User mode	Only operating language		
	Service mode	All values that are not relevant for calibration, e.g. initial parameter settings, date/time, measuring point designation etc.	S-Code	1111
no lock	Programming mode	All parameters can be set, e.g. initial settings, resetting/synchronising of meter readings etc.	P-Code	3132

The codes can be changed in the **Basic setting/System** submenu.




In EU-compliant devices, activating programme mode will result in the invalidation of the calibration! The date and time will be recorded in the calibration log and the device displays an error.



**Warning:** If you change a code, make sure that you keep it in a safe place. If the code is lost, reprogramming is necessary by a service technician on site or in the factory.


# 10 Menu overview

## 10.1 Main display and main menu




## 10.2 Submenus


### Overview Submenu **Measured values**



### Overview Submenu **Operating mode**




## Overview Submenu **Basic setting**




These parameters are only displayed if they are relevant for the selected function

## Overview Submenu **Diagnosis**



# 11 Use under operating conditions

## 11.1 The main display



After switching on the device, the page marked 'start' of the main display appears.

The arrow keys can be used to move between a maximum of 4 pages of the main display:

- ▲ 1: Calibration-relevant data
- ▲ 2: Meter readings and designation
- ▼ 3: Current values
- ▼ 4: other values, if configured
- ▼ Segment test (display test)
- ▼ Error display
- ▼ Main menu

The segment test shows a chequer-board pattern to test the display.

In the error message window, an error message is displayed if an error occurs

In the main menu, the submenus can be selected and displayed to show or set further values.

If no operation is carried out for approx. 5 min., the device will display the main menu marked 'Start'.

### Notes:

The content of the main display depends on the device version. The main display can contain up to four pages with up to four values (i.e. up to 16 values). In standard CALEC® energy master devices, only three pages are displayed with the values shown above.

The display values of the main display are predefined at delivery. These values and their sequence can be altered in a non-CE conformity assessed device using the software AMBUS Win II.

## 11.2 The measured values submenu

### 11.2.1 Measured values

Measured values	
Meter readings	Meter readings for energy, volume (mass)
Current values	Current values: temperatures, volume/mass flow rates, power
Billing date 1 values	Meter readings on the set billing dates
Billing date 2 values	
Logger values	Meter readings per calculator at the set times

### 11.2.2 Meter readings

Meter	Display	calc1, calc2 and 3	Explanation
Energy	E	2: E	Energy meter reading, positive
	E	2: E-	Energy meter reading negative, in options BDE / BDV
Volume	V, V-	2: V, 2: V-	Volume meter reading, E, E- respectively
Mass	M, M-	2: M, 2: M-	Mass meter reading E, E- respectively

### 11.2.3 Current values

Current value	Display	Explanation
Power	P	Thermal power
Volume flow	Qv	Volume flow rate
Mass flow	Qm	Mass flow rate
Temperatures	Th, Tc	Temperature of the heat transfer medium hot / cold side
Temp. difference	dT	Temperature difference: $dT = Th - Tc$
Density	Den	Density of the heat transfer medium (Den: Density)
K-factor	K-F	Heat coefficient
Enthalpy	Hh, Hc	Enthalpy of the heat transfer medium hot / cold side

Current values of calc2 and 3, or with a negative prefix, are displayed similarly ( 2: P or P- ).

If a current value exceeds 999 999 (6 digits), Overflow is displayed

### 11.2.4 Billing date values

Shows the meter readings saved on the two set billing dates. The billing dates can be set under **Operating settings/time settings/Billing** and **Billing2**. The meter readings are saved at 23:59 each time.


### 11.2.5 Logger values

In version 1.0, only the meter readings can be recorded.


Logger values 1	1. Logger value, select with keys  	The time interval for the logger function can be set under <b>Operating settings/Time settings/Logger</b> .
Date/T 01.05.08	Date/time when the value was chosen	
E 24.567 MWh	Energy meter reading at this time	
V 1000.12 m3	Volume meter reading at this time	
M 982.1 t	Mass meter reading at this time	
M 982.1 t	Mass meter reading at the displayed time	

## 12 Dimensional drawings and technical specifications


### 12.1 Drawings of device with protective housing (Prot)



### 12.2 Drawings of device without protective housing (Mod)



## Dimensional drawings of modules with low voltage




In supply module 100-240 VAC and output module 2 x relays 240 VAC, the terminals are protected against accidental contact by two lateral partition walls.

## Dimensional drawing of display module

The dimensions in the diagram refer to the size of the section.

Dimensions of the module are:  
W x H x D: 132 x 72 x 7.8 mm



## 12.3 Technical specifications

Standards	
CE Directives	2004/22/EG (MID) Measuring Instruments Directive 2004/108/EG (EMC) Electromagnetic compatibility 2006/95/EG (LVD) Low voltage directive
Standards	EN 1434, EN 61000-6-2, EN 61000-6-3, EN 60950
EC conformity assessment	Module B, DE-07-MI004-PTB029

Housing, modules	With protective housing	Without protective housing
Mounting	On support rail or wall	On support rail
Protective housing size W x H x D	140 x 202 x 83 mm	
Module housing size W x H x D		3 poles: 17.5 x 117.4 x 63.5 mm 3 poles: 240 V: 17.5 x 129.5 x 63.5 mm 4 poles: 22.5 x 117.4 x 63.5 mm
Type of ingress protection according to EN60529	IP54	IP20
Maximum number of modules	6 – 7, including 1 CPU and 1 supply module, max. 2 communications modules	16, including 1 CPU and 1 supply module, max. 2 communications modules

Environmental conditions	
Ambient temperature during operation	+ 5... +55 °C, EN 1434 class C
Storage temperature	0 °C ... 60 °C
Humidity	Max. 95% rel. humidity, without producing condensation
Cable cross-sections	
Power supply	0.8 ... 2.5 mm <sup>2</sup>
Pulses, frequency, analogue	0.35 ... 2.5 mm <sup>2</sup>
Pt100	0.8 ... 2.5 mm <sup>2</sup> (preferably large)

Power supply	Supply module 100-240VAC
Nominal voltage	100 ... 240 VAC, 50 ... 60 Hz
Operating voltage	86 ... 265 VAC, 47 ... 63 Hz
Current input	Max. 300 mA
Protection class	II
Isolat.-voltage primary/secondary	3000 VAC
additional approvals	UL 60950, EN 60950 (via CSA-NRTL/C)

CPU module 2*Pt100			
Accuracy of energy calculation	Energy error in % Ec <= 20 mK / ΔT (mK) Significantly below EN 1434-1: Ec <= 0.5% + (ΔT/ΔTmin)		
	ΔT [K]	Ec CALEC energy master	Ec EN 1434-1
	3	0.7%	1.5%
	6	0.3%	1%
	20	0.07%	0.65%
	100	0.02%	0.53%

<b>CPU module 2*Pt100</b>	
Data backup in case of power failure	EEPROM > 10 years
Backup battery (button cell)	Lithium 3 V, 48 mAh, Type CR1225, soldered
Life of backup battery	Typically >10 years in normal operation (T < 45 °C) Typically > 6 years without mains supply
Data logger	100 values of all meter readings with time stamp in the ring memory Logger interval: 15 min., 30 min., 1 hr., 1 day, 15 days, 1 month
Billing dates	2 billing dates, dates adjustable
Optical interface	IrDA V1.0 with 57600 baud and M-Bus protocol, max. distance 70 m
Measuring and calculating cycle	1 second

<b>Temperature measurement</b>	<b>CPU-module 2*Pt100 and Input-module 2*Pt100</b>
Temperature range	-50 ... +550 °C according to MID/EN1434: 1 ... 200 °C
Temperature deviation	< ± 10 mK
Temperature differential range	0 ... 550 K according to MID/EN1434: 3 ... 198 K
Deviation ΔT ( Ta = 5 ... 55°C )	< ± 15 mK
Temperature sensor type	Pt 100 (IEC751, paired according to EN1434), 2-, 3- or 4-wire cable
Resolution ADC	24 Bit

<b>Display module</b>	
Dimensions W x H x D	132 x 72 x 7.8 mm
Dimension of cut-out W x H	128 x 68 mm
Display	Alphanumeric LCD, 128 x 64 pixel
Backlight	White, flashes red when fault occurs
Display	Title bar, 4 lines each of 21 characters, status line
Language	Settable: German, English, French, Italian
Keys	6 keys: 4 arrow keys for navigation, OK, Esc
Detachable display module	Max 100 m with Remote Display Adapters (RDA)
Optical interface ( Display module )	IEC 870-5, 300, 2400 or 9600 baud, M-Bus protocol

<b>Input-Module 2*Pulse/frequency/analogue</b>		
Number of inputs	2	
Pulse input	Pulse input: Min. pulse width Types settable according to EN 1434, see below	0.003 ... 12.5 kHz 40 µs
Frequency input	Frequency input Measuring error:	0 ... 10 kHz (PFM) typ. < 0.1%
Analogue input	Measuring range absolute measuring range Accuracy Load Measuring transducer power supply	0 or 4 ... 20 mA 0 ... 22 mA 0.025% full scale, drift 15ppm / K 50 Ω 24V

<b>Input-Module 2*Pulse/frequency/analogue</b>	
Measuring transducer power supply	6, 8 or 24 VDC, settable, max. 25 mA, short-circuit proof
Error detection	Short circuit and interruption (settable)

**Pulse input type according to EN 1434**

	<b>Max. pulse freq.</b>	<b>Pulse length</b>	<b>Input resistance Ri</b>	<b>Meas. transducer power supply</b>
Class IB	5Hz	$\geq$ 100 ms	100 kΩ	6 V
Class IC	200 Hz	$\geq$ 2 ms	100 kΩ	6 V
Class ID	200 Hz	$\geq$ 2 ms	1 kΩ	8 V
Class IE	12.5 kHz	$\geq$ 0.04 ms	1 kΩ	8 V
PFM	12.5 kHz	$\geq$ 0.04 ms	150 Ω	24 V

Switching level: low < 1.5 V, high > 2.1 V, 0.6 V Hysteresis

<b>Output module 2*relays 24V, analogue</b>	
Number of outputs	Two
Output type settable	Relay functions: Pulse / status / limit value / limit value 2 Analogue functions: 0 ... 20 mA / 4 ... 20 mA Test functions: Relay test / analogue test
Relay output (solid state relay)	Max. contact voltage: 24 VDC Max. current: 100 mA Frequency: max. 50 Hz at * * Pulse width: 10 ms, 50 ms, 250 ms, 1 s, settable Duty cycle: 50% Normal state: Contact closed or open, settable Leak current: < 30 μA corresp. to > 800 kOhm at 24 VDC
Analogue output	Current range 0 ... 20 mA or 4 ... 20 mA Accuracy 0.1% full scale, drift 50 ppm / K Max. load $R = (U_{ext} - 4V) / 22 \text{ mA}$
Galvanic isolation	50 V
Measuring transducer power supply	24 VDC, max. 25 mA, short-circuit proof

<b>M-Bus module</b>	<b>M-Bus interface EN1434-3, 2007</b>
Transmission rate	300, 2400, 9600 Baud
Current requirements	1.5 mA (1 M-Bus load)
Addressing	Point-to-point, primary address, secondary address One address per active calculator (max. 3)
Galvanic isolation	Max. 50 V

## 13 EC declaration of conformity



EG-Konformitätserklärung  
EC declaration of conformity  
Déclaration CE de conformité  
Dichiarazione CE di conformità



AQUAMETRO AG, Ringstrasse 75, CH-4106 Therwil

erklärt, dass das Produkt  
declares that the product  
déclare que le produit  
dichiara che il prodotto

Energie-Rechenwerk  
Energy calculator  
Calculateur d'énergie  
Calcolatore d'energia

**CALEC® energy master**

mit den Vorschriften folgender Europäischer Richtlinien übereinstimmt:  
conforms with the regulations of the following European Council Directives:  
est conforme aux prescriptions des suivantes directives Européennes :  
è conforme alle prescrizioni delle seguenti direttive Europee

**2004/108/EG**

EMV Richtlinie  
EMC directive  
Directive CEM  
Direttiva CEM

**2006/95/EG**

Niederspannungsrichtlinie  
Low voltage directive  
Directive sur la tension basse  
Direttiva bassa tensione

Folgende harmonisierte Normen wurden angewendet:

The following harmonised standards or normative documents have been applied

Les normes harmonisées ou documents normatifs ont été appliqués  
è conforme alle prescrizioni delle seguenti direttive Europee

**EN 61000-6-3: 2005 / 2007**

EMV Fachgrundnorm - Störfestigkeit für Wohnbereich, Geschäfts- und Gewerbebereiche sowie Kleinbetriebe  
Generic EMC standards - Immunity for residential, commercial and light-industrial, environments  
Standards CEM génériques - Immunité pour les environnements résidentiels, commerciaux et de petite industrie  
Compatibilità elettromagnetica. Norma generica sull'emissione - Ambienti residenziali, commerciali e dell'industria leggera

**EN 61000-6-2: 2005**

Fachgrundnormen - Störfestigkeit für Industriebereiche  
Generic EMC standards - Immunity for industrial environments  
Standards CEM génériques - Immunité pour les environnements industriels  
Norma specifica - grado di protezione per zone industriali

**EN 61010-1: 2001**

Sicherheitsbestimmungen für elektrische Mess-, Steuer-, Regel- und Laborgeräte; Allgemeine Anforderungen  
Safety requirements for electrical equipment for measurement, control, and laboratory use; General requirements  
Règles de sécurité pour appareils électriques; Prescriptions générales  
Prescrizioni di sicurezza per apparecchi elettrici di misura, regolazione e da laboratorio; Esigenze generali

Prüfstelle, Bericht Testing laboratory, report Laboratoire d'essai, rapport Centro analisi, rapporto	Electrosuisse Montena Montena Montena	06-EL-0061.01, 08. 5.2008 15087 / 20.11.2007 15118 / 19.11.2007 15298 / 17.4.2008



EG-Konformitätserklärung  
EC declaration of conformity  
Déclaration CE de conformité  
Dichiarazione CE di conformità



AQUAMETRO AG, Ringstrasse 75, CH-4106 Therwil

erklärt, dass das Produkt  
declares that the product  
déclare que le produit  
dichiara che il prodotto

Energie-Rechenwerk  
Energy calculator  
Calculateur d'énergie  
Calcolatore d'energia

CALEC® energy master

mit dem Kennzeichen  
with the label  
avec le signe  
con il contrassengno

DE-07-MI004-PTB029  
**CE-M-1259**

mit den Vorschriften folgender Europäischer Richtlinien übereinstimmt:  
conforms with the regulations of the following European Council Directives:  
est conforme aux prescriptions des suivantes directives Européennes :  
è conforme alle prescrizioni delle seguenti direttive Europee:

2004/22/EG

Messgeräterichtlinie  
Measuring Instruments Directive  
Directive sur les équipements de mesure  
direttiva europea relativa agli strumenti di misura

Folgende harmonisierte Normen wurden angewendet:

The following harmonised standards or normative documents have been applied:

Les normes harmonisées ou documents normatifs ont été appliqués:

Sono state applicate le seguenti norme armonizzate o i seguenti documenti normativi:

EN 1434: 2007

Wärmezähler  
Heat meters  
Compteurs de chaleur  
Contatori di calore

Die vorliegende Konformitätserklärung gilt nur in Verbindung mit dem auf dem Messgerät angebrachten CE-Zeichen, gefolgt von der metrologischen Zusatzkennung M und Produktionsjahr, sowie der Ordnungsnummer der Benannten Stelle.

This declaration applies only in conjunction with the CE mark followed by the metrological mark M with the year of manufacture, and the serial number of the notified body both of which are to be found on the measuring device.

La présente déclaration de conformité est valable uniquement en combinaison avec le marquage CE sur l'appareil, suivie par l'adjonction de métrologie identifiant M et l'année de production, ainsi que le numéro d'ordre de l'organisme notifié.

La presente dichiarazione è valida solo in combinazione con il contrassegno CE, seguito dal simbolo metrologico M, anno di fabbricazione e numero di serie dell'organizzazione notificata, predisposto sull'apparecchio.

Benannte Stelle, Bericht, Zulassung Notified body, report, approval Organisme notifié, rapport, homologation Centro verifica, rapporto	PTB Asbeststrasse 2-12 10587 Berlin	DE-07-MI004-PTB029 Notified body Nr. 0102
---	---	--

Therwil, 22.9.2008

Hannes Bock  
Leiter Qualitätsmanagement  
Head Quality Management  
Responsable gestion de qualité  
Direttore gestione qualità

Reinhold Vollmer  
Produkt Management  
Product Management  
Management des produits  
Gestione del prodotto





**Subject to change**

**Copyright © Aquametro AG**

**Art. No. 20765**

Aquametro AG	Aquametro SA	Aquametro	Aquametro	Aquametro s.r.o.
		Messtechnik GmbH	BELGIUM SPRL	
Ringstrasse 75 CH-4106 Therwil	Rue du Jura 10 CH-1800 Vevey	Zum Panrepel 24 D-28307 Bremen	Dallan, 67 B-1933 Sterrebeek	Prosecká 811 / 76a CZ-190 00 Praha
Tel. +41 61 725 11 22 Fax +41 61 725 15 95 info@aquametro.com	Tel. +41 21 926 77 77 Fax +41 21 926 77 78 info@aquametro.com	Tel. +49 421 / 871 64-0 Fax +49 421 / 871 64-19 info.amd@aquametro.com	Tel. +32 2 / 241 62 01 Fax +32 2 / 216 22 63 info.amb@aquametro.com	Tel. +42 02 / 86 88 77 78 Fax +42 02 / 86 88 95 59 info.amc@aquametro.com