

Water meter QALCOSONIC F1 M-bus communication protocol description

1. General structure of protocol

1.1. General features of protocol

Meter uses a M-bus protocol .

Default baud rate: 2400 bps, Even, 1 Stop.

Baud rate can be changed (see paragraph 4.6), but at the end of communication – after 2 minutes it automatically returns to the original 2400 bps.

Protocol is the same for Mbus interface and for optical interface.

Primary address of Mbus is individual for Mbus interface and for optical interface.

1.2. Data strings

Data string to meter SND_NKE:

1	2	3	4	5
10h	40h	A	CS	16h

A - M-bus primary address of meter

CS – control sum (the youngest byte of amount of 2-nd and 3-rd bytes)

Data string to meter SND_UD2:

1	2	3	4	5	6	7	8...n-2	n-1	n
68h	L	L	68h	53h 73h	A	51h	Data	CS	16h

L - length of string (the number of bytes from 5-th to n-2 byte)

A - M-bus primary address of meter

CS – control sum (the youngest byte of amount of 5-th to n-2 bytes)

Data string to meter REQ_UD2:

1	2	3	4	5
10h	5Bh 7Bh	A	CS	16h

A - M-bus primary address of meter

CS – control sum (the youngest byte of amount of 2-nd and 3-rd bytes)

Answer of the meter CON:

E5h

Answer of the meter RSP_UD2:

1	2	3	4	5	6	7	8...11	12, 13	14	15	16	17	18,19
68h	L	L	68h	C	A	CI	ID	Man	Vrs	Md	TC	St	Sign

20 n-2	n-1	n				
DIF	VIF	Data		DIF	VIF	Data		CS	16h				

L - lenght of string (the number of bytes from 5-th to n-2 byte)

C - „C field“ (08)

A - M-bus primary address of meter

CI - „CI field“

ID - identification number of meter (BSD8, used for secondary addressing, can be changed - see paragraph 4.1),

Man - Manufacturer code (AB AxisIndustries manufacturer code „AXI“: 09h 07h)

Vrs - number of protocol version (07h)

Md - code of medium

TC - counter of telegrams

St - meter status code

Sign - 00 00

The bytes 20...n-2 is data from meter:

DIF - code of data format

VIF - code of data units

Data - values of data

CS - control sum (the youngest byte of amount of 5-th to n-2 bytes).

Meter status code byte (St) structure:

Alarm type	Priority	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6	Bit7
Low battery	1	0	0	1	0	0	0	0	0
Permanent error	1	0	0	0	1	0	0	0	0
Dry or temporary error	5	0	0	0	0	1	0	0	0
Backflow	4	0	0	0	0	1	1	1	0
Manipulation	3	0	0	0	0	1	0	1	1
Burst	2	0	0	0	0	1	1	0	1
Leakage	1	0	0	0	0	1	1	0	0

2. Selection of the data type

2.1. Selection of the data type “All data”

Master sends to the meter telegram SND_UD2:

68h	03h	03h	68h	53h 73h	A	50h	CS	16h
-----	-----	-----	-----	------------	---	-----	----	-----

or

68h	04h	04h	68h	53h 73h	A	50h	00h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.2. Selection of the data type “User data”

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	10h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.3. Selection of the data type “Simple billing” (Years logger)

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	20h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.4. Selection of the data type “Enhanced billing” (Days logger)

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	30h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.5. Selection of the data type “Multi tariff billing” (Months logger)

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	40h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.6. Selection of the data type “Instantaneous values”

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	50h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.7. Selection of the data type “Load management values for management” (Hours logger)

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	60h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.8. Selection of the data type “Installation and startup”

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	80h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.9. Selection of the data type “Testing”

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	90h	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

2.10. Parameter list for preselecting

If not satisfied with Default parameter lists (presented in the tables 1 ... 9). Obtain a desired parameter list presented in Table 11th.

(Paragraph 2.1 ... 2.9) Additionally it is need to send parameter selecting telegram SND_UD2:

68h	L	L	68h	53h 73h	A	51h	SEL ₁	SEL ₂	...	SEL _N	CS	16h
-----	---	---	-----	------------	---	-----	------------------	------------------	-----	------------------	----	-----

SEL selecting parameter code from the table of 11 (made out of sequence as many codes as you want to select of the parameters).

Note . It may be selectes as many parameters but Response telegram length can not exceed 250 bytes.

Answer of the meter CON (if A not equal FFh):

E5h

3. Data request

3.1. Data request

Master sends to the meter telegram SND_UD2:

10h	5Bh 7Bh	A	CS	16h
-----	------------	---	----	-----

In all cases, except A = FFh, meter response RSP_UD2 telegrame with selected data (tables 1 ...9)

If no data record, answer of meter is CON:

E5h

3.2. Meter data coding

Table 1

Application reset sub-codes and storages: All data (CI = 50 or CI = 50 00)
Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	
4	Battery operation time	04 20	32 bit integer	sec
5	Working time without error	04 24	32 bit integer	sec
6	Volume	04 13	32 bit integer	m3
7	Pulse input 1 *	84 40 13	32 bit integer	m3
8	Pulse input 2 *	84 80 40 13	32 bit integer	m3
9	Flow rate	05 3E	32 bit float	m3/h
10	Temperature 1	05 5B	32 bit float	°C
11	Serial number	0C 78	32bit BCD8	
12	CRC	02 7F	16 bit integer	CRC16

Table 2

Application reset sub-codes and storages: User data (CI = 50 10)
Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	
4	Battery operation time	04 20	32 bit integer	sec
5	Pulse input 1 *	84 40 13	32 bit integer	m3
6	Pulse input 2 *	84 80 40 13	32 bit integer	m3
7	Pulse value of input 1 *	02 93 28	16 bit integer	m3
8	Pulse value of input 2 *	02 93 29	16 bit integer	m3
9	Pulse value of output 1 *	02 93 2A	16 bit integer	m3
10	Pulse value of output 2 *	02 93 2B	16 bit integer	m3
11	Duration when q < qmin	04 BE 50	32 bit integer	sec
12	Flow min level qmin	05 BE 40	32 bit float	m3/h
13	Duration when q > qmax	04 BE 58	32 bit integer	sec
14	Flow max level qmax	05 BE 48	32 bit float	m3/h
15	Software version	01 FD 0E	8 bit integer	
16	Yearly set day	42 EC 7E	Type G	
17	Monthly set day	42 EC 7E	Type G	
18	Meter type	0D FD 0B	88 bit string	
19	Serial number	0C 78	32bit BCD8	
20	CRC	02 7F	16 bit integer	CRC16

Table 3

Application reset sub-codes and storages: Simple billing (Years logger) (CI = 50 20)
Default list

#	Parameter	DIF VIF	Type	Units
1	Logger date and time	44 6D	32 bit integer	Type F
2	Logger working time without error	44 24	32 bit integer	sec
3	Logger volume	44 13	32 bit integer	m3
4	Logger pulse input 1 *	C4 40 13	32 bit integer	m3
5	Logger pulse input 2 *	C4 80 40 13	32 bit integer	m3
6	CRC	02 7F	16 bit integer	CRC16

Table 4

Application reset sub-codes and storages: Enhanced billing (Days logger) (CI = 50 30)
Default list

#	Parameter	DIF VIF	Type	Units
1	Logger date and time	84 08 6D	32 bit integer	Type F
2	Average temperature 1	85 08 5B	32 bit float	°C
3	Logger working time without error	84 08 24	32 bit integer	sec.
4	Logger volume	84 08 13	32 bit integer	m3
5	Logger pulse input 1 *	84 48 13	32 bit integer	m3
6	Logger pulse input 2 *	84 88 40 13	32 bit integer	m3
7	Logger duration when q > qmax	84 08 BE 58	32 bit integer	m3/h
8	CRC	02 7F	16 bit integer	CRC16

Table 5

Application reset sub-codes and storages: Multi tariff billing (Months logger) (CI = 50 40)
Default list

#	Parameter	DIF VIF	Type	Units
1	Logger date and time	84 08 6D	32 bit integer	Type F
2	Average temperature 1	85 08 5B	32 bit float	°C
3	Logger working time without error	84 08 24	32 bit integer	sec
4	Logger volume	84 08 13	32 bit integer	m3
5	Logger pulse input 1 *	84 48 13	32 bit integer	m3
6	Logger pulse input 2 *	84 88 40 13	32 bit integer	m3
7	Logger duration when q > qmax	84 08 BE 58	32 bit integer	m3/h
8	CRC	02 7F	16 bit integer	CRC16

Remark.

If meter is specially configured, in table 5 listed monthly parameters data is transmitted and in accordance after inquiry ("All data" table 1) data transmission.

Table 6

Application reset sub-codes and storages: Instantaneous values (CI = 50 50)
Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	
4	Battery operation time	04 20	32 bit integer	sec
5	Working time without error	04 24	32 bit integer	sec
6	Volume	04 13	32 bit integer	m3
7	Pulse input 1 *	84 40 13	32 bit integer	m3
8	Pulse input 2 *	84 80 40 13	32 bit integer	m3
9	Flow rate	05 3E	32 bit float	m3/h
10	Temperature 1	05 5B	32 bit float	°C
11	Meter type	04 BE 50	88 bit string	
12	Serial number	0C 78	32bit BCD8	
13	CRC	02 7F	16 bit integer	CRC16

Table 7

Application reset sub-codes and storages: Load management values for management
(Hours logger) (CI = 50 60) Default list

#	Parameter	DIF VIF	Type	Units
1	Logger date and time	C4 86 03 6D	32 bit integer	Type F
2	Average flow	C5 86 03 3E	32 bit float	m3/h
3	Average temperature 1	C5 86 03 5B	32 bit float	°C
4	Logger min flow	E5 86 03 3E	32 bit float	m3/h
5	Logger max flow	D5 86 03 3E	32 bit float	m3/h
6	Logger error code	F4 86 03 FD 17	32 bit integer	
7	Logger working time without error	C4 86 03 24	32 bit integer	sec
8	Logger volume	C4 86 03 13	32 bit integer	m3
9	Logger pulse input 1 *	C4 C6 03 13	32 bit integer	m3
10	Logger pulse input 2 *	C4 86 43 13	32 bit integer	m3
11	Logger duration when $q > q_{max}$	C4 86 03 BE 58	32 bit integer	m3/h
12	CRC	02 7F	16 bit integer	CRC16

Table 8

Application reset sub-codes and storages: Installation and startup (CI = 50 80)
 Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	
4	Battery operation time	04 20	32 bit integer	sec
5	Working time without error	04 24	32 bit integer	sec
6	Flow min level qmin	05 BE 40	32 bit float	m3/h
7	Flow max level qmax	05 BE 48	32 bit float	m3/h
8	Test mode status	01 FF 03	8 bit integer	
9	Device mode status	01 FF 04	8 bit integer	
10	Software version	01 FD 0E	8 bit integer	
11	Yearly set day	42 EC 7E	Type G	
12	Monthly set day	42 EC 7E	Type G	
13	Meter type	0D FD 0B	88 bit string	
14	Serial number	0C 78	32bit BCD8	
15	CRC	02 7F	16 bit integer	CRC16

Table 9

Application reset sub-codes and storages: Testing (CI = 50 90)
 Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	
4	Battery operation time	04 20	32 bit integer	sec
5	Flow rate	05 3E	32 bit float	m3/h
6	Temperature 1	05 5B	32 bit float	°C
7	Pulse value of energy test output	02 FF 01	16 bit integer	
8	Pulse value of volume test output	02 FF 02	16 bit integer	
9	Test mode status	01 FF 03	8 bit integer	
10	Device mode status	01 FF 04	8 bit integer	
11	Volume high resolution	04 01	32 bit integer	mWh
12	Device configuration	01 FF 09	8 bit integer	
13	Software version	01 FD 0E	8 bit integer	
14	Device type	0D FD 0B	88 bit string	
15	Serial number	0C 78	32bit BCD8	
16	CRC	02 7F	16 bit integer	CRC16

Table 10
Error code encryption

Byte N	Bite N	if bite = 1	LCD indication code "ERROR xxxx"
0	0	-	
	1	-	
	2	Hardware status flag Er02	8000
	3	Hardware status flag Er03	8000
	4	End of battery live time	1000
	5	Hardware status flag Er05	0008
	6	-	
	7	-	
1	0	Leakage	0100
	1	Burst	0200
	2	Flow sensor is empty	0001
	3	Flow flows in a reverse direction	0002
	4	Flow rate less q1	
	5	-	
	6	-	
	7	-	
2	0	Temperture sensor 1 error or short circuit	0080
	1	Temperture sensor 1 disconected	0080
	2	Temperture 1 < 0°C	00C0
	3	Temperture 1 > 180°C	0080
	4	-	
	5	-	
	6	-	
	7	-	
3	0	Hardware status flag Er30	0880
	1	-	
	2	-	
	3	-	
	4	Flow rate greater 1,2qs	0004
	5	Hardware status flag Er35	8000
	6	-	
	7	Hardware status flag Er37	8000

Parameters list for preselecting

Table 11

#	Parameter	SEL	DIF VIF					Type	Units
			CI = 50 Instantaneous	CI = 50 60 Hours logger	CI = 50 30 Days logger	CI = 50 40 Months logger	CI = 50 20 Years logger		
1	Date and time stamp	C8 FF 7F 6D	04 6D	C4 86 03 6D	84 08 6D	84 08 6D	44 6D	32 bit integer	Type F
2	Working time without error	C8 FF 7F 24	04 24	C4 86 03 24	84 08 24	84 08 24	44 24	32 bit integer	sec
3	Error code	F8 FF 7F FD 17	34 FD 17	F4 86 03 FD 17	B4 08 FD 17	B4 08 FD 17	74 FD 17	32 bit integer	
4	Date and time of error starting	F8 FF 7F 6D	34 6D	-	-	-	-	32 bit integer	Type F
5	Volume	C8 FF 7F 13	04 13	C4 86 03 13	84 08 13	84 08 13	44 13	32 bit integer	m3
6	Pulse input 1 *	C8 FF 3F 7E	84 40 13	C4 C6 03 13	84 48 13	84 48 13	C4 40 13	32 bit integer	m3
7	Pulse input 2 *	C8 BF 7F 7E	84 80 40 13	C4 86 43 13	84 88 40 13	84 88 40 13	C4 80 40 13	32 bit integer	m3
8	Averago Flow rate	C8 FF 7F 3E	05 3E	C5 86 03 3E	85 08 3E	85 08 3E	45 3E	32 bit float	m3/h
9	Average Temperature 1	C8 FF 7F 5B	05 5B	C5 86 03 5B	85 08 5B	85 08 5B	45 5B	32 bit float	°C
10	Min Flow rate	E8 FF 7F 3E	-	E5 86 03 3E	A5 08 3E	A5 08 3E	65 3E	32 bit float	m3/h
11	Min Flow rate Date	E8 FF 7F BE 6D	-	E4 86 03 BE 6D	A4 08 BE 6D	A4 08 BE 6D	64 BE 6D	32 bit integer	Type F
12	Max Flow rate	D8 FF 7F 3E	-	D5 86 03 3E	95 08 3E	95 08 3E	55 3E	32 bit float	m3/h
13	Max Flow rate Date	D8 FF 7F BE 6D	-	D4 86 03 BE 6D	94 08 BE 6D	94 08 BE 6D	54 BE 6D	32 bit integer	Type F
14	Min Temerature 1	E8 FF 7F DB 6D		E5 86 03 5B	A5 08 5B	A5 08 5B	65 5B	32 bit float	°C
15	Min Temerature 1 Date	E8 FF 7F DB 6D	-	E4 86 03 DB 6D	A4 08 DB 6D	A4 08 DB 6D	64 DB 6D	32 bit integer	Type F
16	Max Temperature 1	D8 FF 7F 5B	-	D5 86 03 5B	95 08 5B	95 08 5B	55 5B	32 bit float	°C
17	Max Temperature 1 Date	D8 FF 7F DB 6D	-	D4 86 03 DB 6D	94 08 DB 6D	94 08 DB 6D	54 DB 6D	32 bit integer	Type F
18	Duration when q < qmin	C8 FF 7F BE 50	04 BE 50	C4 86 03 BE 50	84 08 BE 50	84 08 BE 50	44 BE 50	32 bit integer	sec
19	Flow min level qmin	C8 FF 7F BE 40	05 BE 40	-	-	-	-	32 bit float	m3/h
20	Duration when q > qmax	C8 FF 7F BE 58	04 BE 58	C4 86 03 BE 58	84 08 BE 58	84 08 BE 58	44 BE 58	32 bit integer	sec
21	Flow max level qmax	C8 FF 7F BE 48	05 BE 48	-	-	-	-	32 bit float	m3/h
22	Battery operation time	C8 FF 7F 20	04 20	-	-	-	-	32 bit integer	sec
23	Volume high resolution	C8 FF 7F 01	04 01	-	-	-	-	32 bit integer	

Remark.

Table 1...11 parameters marked “*”, will be transmitted only if the conditions are kept:

Table 12

Parameter	Condition
Pulse input 1, Logger pulse input 1	Pulse input 1 is active
Pulse input 2, Logger pulse input 2	Pulse input 2 is active
Pulse value of output 1	Pulse output 1 is active
Pulse value of output 2	Pulse output 2 is active

3.3. CRC16 checksum calculation algorithm

```

/*
 * The polynomial x^0 + x^5 + x^12.
 */
const __u16 crc_ccitt_table[256] = {
    0x0000, 0x1189, 0x2312, 0x329b, 0x4624, 0x57ad, 0x6536, 0x74bf,
    0x8c48, 0x9dc1, 0xaf5a, 0xbcd3, 0xca6c, 0xdbef, 0xe97e, 0xf8f7,
    0x1081, 0x0108, 0x3393, 0x221a, 0x56a5, 0x472c, 0x75b7, 0x643e,
    0x9cc9, 0x8d40, 0xbfdb, 0xae52, 0xdaed, 0xcb64, 0xf9ff, 0xe876,
    0x2102, 0x308b, 0x0210, 0x1399, 0x6726, 0x76af, 0x4434, 0x55bd,
    0xad4a, 0xbcc3, 0x8e58, 0x9fd1, 0xeb6e, 0xfae7, 0xc87c, 0xd9f5,
    0x3183, 0x200a, 0x1291, 0x0318, 0x77a7, 0x662e, 0x54b5, 0x453c,
    0xbdcb, 0xac42, 0x9ed9, 0x8f50, 0xfbef, 0xea66, 0xd8fd, 0xc974,
    0x4204, 0x538d, 0x6116, 0x709f, 0x0420, 0x15a9, 0x2732, 0x36bb,
    0xce4c, 0xdfc5, 0xed5e, 0xfcfd, 0x8868, 0x99e1, 0xab7a, 0xbaf3,
    0x5285, 0x430c, 0x7197, 0x601e, 0x14a1, 0x0528, 0x37b3, 0x263a,
    0xdecd, 0xcf44, 0xfdff, 0xec56, 0x98e9, 0x8960, 0xbbfb, 0xaa72,
    0x6306, 0x728f, 0x4014, 0x519d, 0x2522, 0x34ab, 0x0630, 0x17b9,
    0xef4e, 0xfec7, 0xcc5c, 0xdd5, 0xa96a, 0xb8e3, 0x8a78, 0x9bf1,
    0x7387, 0x620e, 0x5095, 0x411c, 0x35a3, 0x242a, 0x16b1, 0x0738,
    0xffcf, 0xee46, 0xcdcd, 0xcd54, 0xb9eb, 0xa862, 0x9af9, 0x8b70,
    0x8408, 0x9581, 0xa71a, 0xb693, 0xc22c, 0xd3a5, 0xe13e, 0xf0b7,
    0x0840, 0x19c9, 0x2b52, 0x3adb, 0x4e64, 0x5fed, 0x6d76, 0x7cff,
    0x9489, 0x8500, 0xb79b, 0xa612, 0xd2ad, 0xc324, 0xf1bf, 0xe036,
    0x18c1, 0x0948, 0x3bd3, 0x2a5a, 0x5ee5, 0x4f6c, 0x7df7, 0x6c7e,
    0xa50a, 0xb483, 0x8618, 0x9791, 0xe32e, 0xf2a7, 0xc03c, 0xd1b5,
    0x2942, 0x38cb, 0xa50, 0x1bd9, 0x6f66, 0x7eef, 0x4c74, 0x5dfd,
    0xb58b, 0xa402, 0x9699, 0x8710, 0xf3af, 0xe226, 0xd0bd, 0xc134,
    0x39c3, 0x284a, 0x1ad1, 0x0b58, 0x7fe7, 0x6e6e, 0x5cf5, 0x4d7c,
    0xc60c, 0xd785, 0xe51e, 0xf497, 0x8028, 0x91a1, 0xa33a, 0xb2b3,
    0x4a44, 0x5bcd, 0x6956, 0x78df, 0x0c60, 0x1de9, 0x2f72, 0x3efb,
    0xd68d, 0xc704, 0xf59f, 0xe416, 0x90a9, 0x8120, 0xb3bb, 0xa232,
    0x5ac5, 0x4b4c, 0x79d7, 0x685e, 0x1ce1, 0x0d68, 0x3ff3, 0x2e7a,
    0xe70e, 0xf687, 0xc41c, 0xd595, 0xa12a, 0xb0a3, 0x8238, 0x93b1,
    0x6b46, 0x7acf, 0x4854, 0x59dd, 0x2d62, 0x3ceb, 0x0e70, 0x1ff9,
    0xf78f, 0xe606, 0xd49d, 0xc514, 0xb1ab, 0xa022, 0x92b9, 0x8330,
    0x7bc7, 0x6a4e, 0x58d5, 0x495c, 0x3de3, 0x2c6a, 0x1ef1, 0x0f78
};

/*
 *      crc_ccitt - recompute the CRC for the data buffer
 *      @crc - previous CRC value
 *      @buffer - data pointer
 *      @len - number of bytes in the buffer
 */
__u16 crc_ccitt(__u16 crc, __u8 const *buffer, size_t len)
{
    while (len--)
        crc = (crc >> 8) ^ crc_ccitt_table[(crc ^ (*buffer++)) & 0xff];
    return crc;
}

```

4. Settings the parameters of meter

4.1. Changing the identification number

Master sends to the meter string SND_UD2 with new identification number „ID“ (BCD8 format):

68h	09h	09h	68h	53h 73h	A	51h	0Ch	79h	ID	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	-----	----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

4.2. Changing the identification number, Manufacturer ID and Medium

Master sends to the meter string SND_UD2 with new Complete ID (64 bit integer):

68h	09h	09h	68h	53h 73h	A	51h	07h	79h	Complete ID (64 bit)	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	-----	----------------------	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

Structure of “Complete ID” (64 bit integer):

Identification number „ID“ 4 byte (BCD8 format)	Manufacturer ID 2 byte	Generation 1 byte	Medium 1 byte

Remark: Generation code is ignored (In meter Generation code is fixed 07h)

4.3. Changing the primary address

Master sends to the meter string SND_UD2 with new primary address „aa“:

68h	06h	06h	68h	53h 73h	A	51h	01h	7Ah	aa	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	-----	----	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

4.4. Changing the data and time of the meter

Master sends to the meter string SND_UD2 with new data and time:

68h	09h	09h	68h	53h 73h	A	51h	04h	6Dh	Dat and time (Type F)	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	-----	-----------------------	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

4.5. Changing the yearly set day

Master sends to the meter string SND_UD2 with new set data :

68h	08h	08h	68h	53h 73h	A	51h	42h	ECh	7Eh	Month and day (Type G)	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	-----	-----	------------------------	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

4.6. Changing the monthly set day

Master sends to the meter string SND_UD2 with new set data :

68h	09h	09h	68h	53h 73h	A	51h	82h	08h	ECh	7Eh	Day (Type G)	CS	16h
-----	-----	-----	-----	------------	---	-----	-----	-----	-----	-----	--------------	----	-----

Answer of the meter CON (if A not equal FFh):

E5h

Remark. Changig the identification number and the set date is possible only when meter is set to TEST mode.

4.7. Changing the baud rate

Master sends to the meter string SND_UD2 with new baud rate code „BR“:

68h	03h	03h	68h	53h 73h	A	BR	CS	16h
-----	-----	-----	-----	------------	---	----	----	-----

Answer of the meter CON (if A not equal FFh) with old baud rate:

E5h

Values of BR code:

BR=B8h – for changing boud rate to 300 bps
 BR=B9h – for changing boud rate to 600 bps
 BR=BAh – for changing boud rate to 1200 bps
 BR=BBh – for changing boud rate to 2400 bps
 BR=BCh – for changing boud rate to 4800 bps
 BR=BDh – for changing boud rate to 9600 bps
 BR=BFh – for changing boud rate to 19200 bps

5. Secondary addressing

5.1. Selecting of the meter

Master sends to the meter string SND_UD2 :

68h	0Bh	0Bh	68h	53h 73h	FD	52	NN	NN	NN	HH	HH	ID	MM	CS	16h
-----	-----	-----	-----	------------	----	----	----	----	----	----	----	----	----	----	-----

NN – Identification number (secondary adress) BCD8 format (if „F“- this number ignored)
 HH – Manufacturer code, HST format (if „FF“- this byte ignored)
 ID – Identification code, HST format (if „FF“- ignored)
 MM – Medium code, SMED format (if „FF“- ignored)

The meter, whose identification number is the same, is selected for further communication and send answer CON:

E5h

5.2. Communication with selected meter

Communication with selected meter carried out as usual:

- data type for reading is selected by sending to meter strig SND_UD2 (see paragraph 2), only in this case, M-bus adress must be FDh,

- answer of the selected meter CON :

E5h

- for data request master sends to the meter string (M-bus adress must be FDh):

10h	5Bh 7Bh	FDh	CS	16h
-----	------------	-----	----	-----

- meter response RSP_UD2 telegrame with selected data (tables 1 ...9)

5.3. Deselection of seccondary addresing mode

Master sends to the meter telegram SND_NKE with adress FDh :

10h	40h	FDh	CS	16h
-----	-----	-----	----	-----